

Fassungsvermögen des Bechers: ca. 500 ml

Ihr Coffee-to-go-Becher aus doppelwandigem Edelstahl hält Ihre Getränke bis zu 12 Stunden warm oder kalt. Damit Sie lange Freude an Ihrem Becher haben, beachten Sie bitte die folgenden Hinweise:

Vor dem ersten Gebrauch

Spülen Sie den Becher vor dem ersten Gebrauch mehrmals mit warmem Wasser und Spülmittel.

Reinigung

Reinigen Sie den Becher von Hand. Verwenden Sie keine aggressiven Spülzusätze, Alkohol, Spiritus oder säurehaltige Mittel. Um Rückstände zu entfernen, können Sie den Becher von Zeit zu Zeit mit heißem Essigwasser reinigen. Auf der bedruckten Oberfläche keine Scheuermittel oder Scheuerschwämme verwenden.

**Sicherheit**

- Der Isolierbecher ist nicht für Kinder geeignet, da erhöhte Gefahr von Verbrennungen und Verbrühungen besteht.
- Es besteht Verbrühungsgefahr durch Dampfdruck. Lassen Sie beim Aufsetzen des Deckels die Trinköffnung im Deckel geöffnet. So kann der heiße Dampf entweichen. Lassen Sie heiße Flüssigkeiten immer etwas abkühlen, bis weniger Dampf aufsteigt, bevor Sie die Trinköffnung schließen. Anderenfalls kann sich zu viel Dampf ansammeln, sodass der Deckel sich hebt. Öffnen Sie die Trinköffnung auch, bevor Sie den Deckel abnehmen, um den Druck zu mindern.
- Der Becher ist nicht für die Mikrowelle geeignet.
- Der Becher ist nicht für kohlenensäurehaltige Getränke geeignet.
- Transportieren Sie den Becher aufrecht, da der Inhalt sonst auslaufen kann.
- Nicht auf warme Herdplatten, neben Wärmequellen oder in den Backofen stellen.
- Keine Eiswürfel einfüllen.
- Nicht für milchhaltige Getränke oder Babynahrung verwenden (Gefahr von Bakterienbildung).

Gerth Medien in der SCM Verlagsgruppe GmbH
Dillerberg 1
35614 Asslar
Germany

Operating Instructions

Cup capacity: approx. 500 ml

Your coffee-to-go mug made of double-walled stainless steel keeps your drinks hot or cold for up to 12 hours. To ensure that you enjoy your mug for a long time, please observe the following instructions:

Before first use

Rinse the mug several times with warm water and dishwashing liquid before first use.

Cleaning

Clean the mug by hand. Do not use aggressive rinsing additives, alcohol, spirit or acidic agents. To remove residues, you can clean the mug with hot vinegar water from time to time. Do not use abrasive cleaners or scouring pads on the printed surface.

**Safety**

- The insulated mug is not suitable for children due to increased risk of burns and scalds.
- There is a risk of scalding due to steam pressure. When placing the lid, leave the drinking opening in the lid open. This allows the hot steam to escape. Always allow hot liquids to cool down slightly until less steam rises before closing the drinking opening. Otherwise, too much steam may accumulate, causing the lid to lift. Also open the drinking opening before opening the lid to relieve pressure.
- The mug is not suitable for microwave use
- The cup is not suitable for carbonated beverages.
- Transport the cup upright, otherwise the contents may leak.
- Do not place on hot stove tops, next to heat sources or in the oven.
- Do not fill with ice cubes.
- Do not use for beverages containing milk or baby food (risk of bacteria formation).

Gerth Medien in der SCM Verlagsgruppe GmbH
Dillerberg 1
35614 Asslar
Germany